


Thank you for choosing Pacefeeder, the 'Slow Hay Feeder'  
designed and manufactured in Ireland.  
[www.pacefeeder.ie](http://www.pacefeeder.ie)

## PACEFEEDER INSTRUCTIONS



- 1 Fitting** - On the exterior of the left & right sides, there are templates for bolts holes. It is necessary to secure the Pacefeeder into the corner of a stable. Two lugs are provided as an alternative, to secure the feeder to a post and rail fence (Paddock or turn out)
- 2 Filling** - Release the ball cord from the black rope cleat on the left and right hand side and undo them from the grid. Lift up the grid to the right, to stand vertically against the wall. Fill the Pacefeeder with Hay - break out the leaves so it is not too compact. The hay should be fairly level, place the grid back on top of the hay. Rethread the ball-cords through the hole in the grid then place it back through the hole on the left & right side and pull through the black rope cleat.
- 3 False Floor** To drain any water open bung or drill holes in the bottom floor. The Pacefeeder should be on a raised level to allow the water to escape. Remove the false floor in order to scoop out dust / seeds that has collected in the bottom of the feeder .
- 4 Cleaning** - It is advised to clean your Pacefeeder with a disinfectant such as Steri-7 (Disinfectant approved by the Irish Equine Centre) and spray it with water.
- 5 Spare Parts** - There are spares available to buy - just contact us by email. ([info@pacefeeder.ie](mailto:info@pacefeeder.ie))
- 6 Feedback** - Your feedback is most welcome on our Facebook page or website.
- 7 Habituation** for the horse should be over a few days to allow for the change. Initially place the hay 50% under the grid and 50% over the grid. A small amount of hay should be pulled through the holes in the grid to allow the horse to get started (a bit like a box of tissues) If the grid is placed flat on the surface of the hay it can be difficult for the horse to pullout the hay using its prehensile lip.